

## Motor Mount

- 75 mm
- 98 mm

# ALL FIBERGLASS

# MEGA

# Cowabunga™

## Specifications

Length: 54.5"  
Diameter 8"  
Weight: 27 lbs  
Motor Mount: 75 or 98mm  
Fins: 3 - 3/16" G10  
CP: 40" from nose tip


## Parts List

- (1) Fiberglass Nose Cone
- (1) Pre-slotted main body tube (30")
- (2) Centering rings
- (1) Bulkheads
- (1) 75mm or 98mm Motor tube
- (3) 3/16" G10 fins
- (2) U-bolts

## You'll need these items to complete this kit

- Epoxy
- Rail Buttons
- Filler and Paint
- Zap or CA Super Glue
- Motor Retainer
- 60/80 Sandpaper
- Pencil

K-168



8 98666 00168 0

 **madcow Rocketry**  
put some fun in your rockets!

Please make sure you read all directions and understand how to assemble your model before you start construction. It is also a good idea to test fit each part before assembly.

Fiberglass parts still contain small amounts of mold release and other materials on the surface that will inhibit adhesives and/or paint. It is important to clean each part prior to assembly with a solution of 1 part rubbing alcohol, 3 parts water and a drop of dish washing soap. **IMPORTANT:** do not sand any parts until after you have cleaned them - you will embed the materials you are trying to clean making it difficult to clean.

Some G10 parts may have holding tabs left over from the CNC machine. These small tabs will need to be sanded off before assembly.

Use only a high quality epoxy like Aeropoxy or West System to bond parts together. You can use a colloidal silica filler like West System 404 or 406 to thicken epoxy when making fillets. When using a filler for fillets a consistency like peanut butter or syrup is best. For extra strength you can add 1/16" or 1/32" milled glass fiber.

**IMPORTANT:** Before assembling any part with epoxy, rough up the surface to be epoxied using 60-80 sandpaper. The scratches in the fiberglass surface will give the epoxy something to grab onto. Epoxy will not soak into the fiberglass like wood or cardboard - epoxy will not grip very well to fiberglass without this rough surface. You can use Zap or CA glue to tack parts into place before you apply epoxy.



**IMPORTANT:** If you plan to fly this rocket with a motor that does not have motor ejection, you will need to plan and construct an altimeter bay (parts not included). It is best to decide this before you start constructing the rocket.

- Step 1 - Start by drilling and mounting one of the U-Bolts to one of the centering rings. Put 2 nuts on the U-Bolt first, place the U-Bolt onto the centering ring followed by the mounting plate, washers and 2 more nuts.. Secure the nuts with epoxy so they do not come loose later.



- Step 2 - Sand the outside of the motor tube to rough up the surface for the epoxy to stick to.



- Step 3 - Mark the motor tube 1/2" from one end of the motor tube. Epoxy the centering ring, with the U-Bolt you just mounted, at the mark. Make sure you have the U-Bolt facing up - this will be the forward centering ring. **IMPORTANT:** make sure the motor tube is clean of epoxy because the fin roots will need a clean surface to attach to.



- Step 4 - Sand the body tube for at least 1/2" around the fin slots inside and outside to rough the surface for the fin fillets. Also sand where the centering ring will attach in front of the fin slots on the inside. You can wrap sand paper around a large dowel to help sand the inside of the body tube.



- Step 5 - Test fit each of the fins in the fin slots and file the slots to make sure you have a snug but smooth fit. Also sand the sides of the fin tangs so the entire tang plus at least 1/2" of the exposed fin above the body tube is roughed up so epoxy will stick to the fin. You can clean any residue from the machining process using acetone. It is a good idea to number your fins and slots to remember which fin fits best in what slot.
- Step 6 - Test fit the aft centering ring on the motor tube and inside the body tube. Sand for a snug but easy fit. Wrap the aft centering ring in plastic wrap for the next step. **IMPORTANT:** you will not be gluing the aft ring on yet, only using it to align the motor tube.

- Step 7 - Test fit the motor tube assembly inside the body tube to ensure a smooth fit. The centering ring with the U-Bolt should go in first. When you are satisfied with the fit, spread epoxy on the inside of the body tube above the fin slots and slide the motor tube in until the centering ring clears the fin slot. Make sure any fillet on the forward centering ring is clear of the slot also so the fin root can seat against the motor tube. The aft end of the motor tube should extend 1" aft of the fin slot if you are going to use a retainer that goes onto the motor tube, or extend about 1/2" aft of the fin slot if you are going to use a flange mount retainer. **IMPORTANT:** do not use epoxy on the aft centering ring yet. Insert the aft centering ring inside the aft end of the rocket to make sure the aft end of the motor tube remains centered while the epoxy sets.

- Step 8 - Apply an epoxy fillet on the forward side of the forward centering ring where it meets the body tube.



- Step 9 - Use a door jamb to mark half way between two fins on the slotted main body tube. This line will be used later to align the rail buttons.



- Step 10 - With the aft centering ring temporarily still in place, tack each of the fins in place using CA on the root edge of the fin. Make sure each fin seats properly to the motor tube before applying CA. Readjust your slot if needed. Also CA along the body tube/fin joint to keep the fin from sliding when you remove the aft centering ring later. **IMPORTANT:** make sure you do not accidentally glue the aft centering ring in place. Remove the aft centering ring after the glue sets.

- Step 12 - Use the same epoxy consistency to form fillets on the outside fin/body tube joint.



- Step 11 - It is a good idea to use masking tape to seal the outside of all the fin/body tube joints for this step in case there are any gaps where epoxy can leak through. Mix some epoxy and use milled glass to make a thick syrup like consistency. Pour the mixture down each fin line between the motor tube and body tube. Use a dowel and spread epoxy forming a fillet on all fin to motor tube joints and internal fin to body tube joints. Make sure you get a good fillet on the entire fin because this is main strength point of the fin joint. Failure to get a good solid strong joint at this point can lead to a fin separation in flight. You can use plastic syringes here if you want to help place the epoxy accurately. **IMPORTANT:** make sure you keep the motor tube clean aft of the fin where the aft centering ring will go.

- Step 13 - Test fit the aft centering ring. You may want to pre-drill any motor retainer holes at this point also. Epoxy the aft centering ring in place. Follow the manufacturers directions and attach the motor retainer at this point.



- Step 14 - Drill a 1/8" vent hole just forward of the forward centering ring.
- Step 15 - Pack the chutes and assemble the rocket. Insert the largest motor that you intend to fly (or simulate the weight with an appropriate substitute) and ensure that the CG is at least 1/2 body diameter in front of the estimated CP point specification on the first page. The estimated CP should be measured from the tip of the nose cone. If the CG is too far back, add weight inside the nose cone by pouring lead shot into the nose cone and adding some epoxy.
- Step 16 - Drill and mounting one of the U-Bolts to the nose cone bulkplate. Secure the nuts with epoxy so they do not come loose later.



- Step 17 - Test fit the bulkhead in the shoulder of the nose cone. When you are satisfied with the fit, epoxy in place and add a fillet around the edge to reinforce this joint.



- Step 18 - At this point rig the recovery system with your choice of shock cord..
- Step 19 - Your model is now ready to paint and fly.

Now go have some fun!

## Flying Your Model

**IMPORTANT:** always use positive motor retention to secure the motor. Failure to use motor retention will cause the motor to be ejected instead of the parachute making for a dangerous ballistic reentry.

**IMPORTANT:** Proper CG is critical to the stability of this model. This model may require some ballast in the nose - the amount will depend on how you build and the size motor you use to fly. Do not fly without balancing this model properly as a dangerous unstable flight will result.

**IMPORTANT:** Always follow the NAR safety code and remember that rockets are not toys and can be dangerous if not prepared and used properly. If you are a beginner, it is a good idea to fly with a club or other group of experienced rocketeers until you have gained some experience.

**IMPORTANT:** In no event shall Madcow Rocketry be liable for any direct, indirect, punitive, incidental, special consequential damages whatsoever arising out of or connected with the use or misuse of it's products. The buyer assumes all risk and liability resulting from ANY use of any and all products sold by Madcow Rocketry. Your purchase and use of any Madcow Rocketry product constitutes your agreement to and acceptance of these terms. If you do not agree to these terms and conditions, you must return the unused product in resalable condition for a refund or credit.

**IMPORTANT:** Please contact us via phone or email if you have any questions about constructing or flying your model.



24338 El Toro Rd #E-134

Laguna Woods, CA 92637

949.547.8847

[www.madcowrocketry.com](http://www.madcowrocketry.com)

[support@madcowrocketry.com](mailto:support@madcowrocketry.com)

©2011 MadCow Rocketry™